



BMW 316i - engine start sporadically not possible

Data sheet	
Manufacturer	BMW
Vehicle model	316i F30
Engine	Engine code: N13 B16A
Year of manufacture	from 2012 to 2015
Symptoms	It is sporadically not possible to start the engine

Important safety note

Engine does not start - error code P302C stored

Engine starting problems may occur sporadically with the above-mentioned vehicle type. Error P302C and/or P0087 "Pressure on high-pressure fuel system too low" stored in the error memory of the engine control unit.

If no direct fault is found in the periphery of the fuel system during troubleshooting, a possible cause of the fault may be a defective fuel pump relay.

In this case, the supply voltage is to be checked directly at the fuel pump using a suitable measuring device.

To do this, please proceed as follows:

- Expose the plug connection on the fuel pump
- Connect the measuring tips to the plug connection of the fuel pump on the vehicle side in accordance with the circuit diagram
- Switch on the ignition and start the engine
- At least 12 volts of supply voltage should be present here when the engine is started
- If no supply voltage can be measured, the fuel pump relay should be first replaced
- Then repeat the measurement

On this vehicle type, the fuel pump relay is located behind the side section of the rear seat's backrest on the right in the direction of travel.

Once the cause of the fault has been removed, delete the error memory and then finally carry out a test drive.



IMPORTANT

Please always observe in such cases the maintenance and repair notes provided by the vehicle manufacturer.


In certain cases, this information can also apply to other vehicle series.

For your own safety and the safety of other road users, test and trial drives must always be carried out with a second person (driver) present.

2 7P

12gn

30



K49

87

86

1

12bl

12sn

C17



2

(1)

Caption: 1. Fuel pump relay 2. Fuel pump

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval; indication of the document source is also required. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.