

Verificar a excentricidade lateral do disco de travão | HELLA

Geral De modo a prevenir prematuramente vibrações durante a travagem, deve-se controlar a planeza do novo disco de travão com um relógio comparador adequado. A verificação da excentricidade lateral é realizada com o disco de travão montado no veículo. Durante estes trabalhos devem ser considerados os dados técnicos do veículo, do respetivo fabricante automóvel. Valor de referência: desvio máx. da excentricidade lateral de 0,07 mm. Verificação Recomenda-se o seguinte procedimento. Montar o disco de travão com todos os parafusos ou porcas das rodas e respetivas anilhas ou distanciadores no cubo da roda. Fixar o suporte do relógio comparador na pata telescópica. Posicionar o relógio comparador cerca de 10-15 mm abaixo do raio externo do disco e ajustar em "zero". Rodar o disco de travão no sentido de marcha. Ler e apontar os valores de medição. Os eventuais desvios devem ser medidos durante várias revoluções do disco e não devem exceder as tolerâncias! Aviso de reparação Esta verificação apenas é fidedigna em discos de travão novos ou seminovos. Em caso de desvios, deve ter-se em consideração o estado do cubo da roda e do rolamento, que poderão ser uma possível fonte de avarias adicional. Observar neste contexto sempre as instruções de manutenção e de reparação dos respetivos fabricantes automóveis.

In order to avoid the problem of brake judder when driving as early as possible, the axial runout of the new brake disc should be tested using a suitable dial gauge. The check of lateral runout is performed with the brake disc installed. The vehicle-specific specifications of the respective vehicle manufacturer are binding.

Guide value: Max. permissible lateral runout 0.07mm

Tests

The following procedure is recommended.

1. Install the brake disc on the wheel hub as prescribed with all wheel bolts or wheel nuts, and the corresponding washers and shims.
2. Fasten the dial gage with holder to the suspension strut.
3. Place the dial gage approx. 10 - 15 mm below the outer radius of the disc and align with 'zero'.
4. Turn the brake disc in the direction of travel.

5. Read off the measured values and note

Measured over several wheel revolutions, deviations should not exceed the respective tolerance values.



Repair note

- This test should only be carried out on brake discs that are new or like new.
- If deviations are found, the state of the wheel hub and bearing should be considered as further fault sources.

Please always observe the specifications in the maintenance and repair notes provided by the respective vehicle manufacturer.

Important safety note

Technical information and practical tips have been compiled by HELLA in order to provide professional support to vehicle workshops in their day-to-day work. The information provided on this website is intended for use by suitably qualified personnel only.

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval and indication of the source. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.