



Nissan Juke - oil consumption: Oil level warning lamp lights up

Data sheet	
Manufacturer	Nissan
Vehicle model	Juke (F15)
Engine	1.2i
Engine code	HRA20DDT
Year of manufacture	2010 - 2020
Symptoms	Oil level warning lamp lights up/Oil requirement

Important safety note

Oil level warning lamp comes on in Nissan Juke

If the warning lamp for the engine oil level lights up on the vehicles mentioned above, the oil level must be checked immediately and, if necessary, oil must be added. Checking the oil level at regular intervals is recommended. If the oil level is detected as being too low repeatedly, this may be caused by the induction pipe pressure being too low.

Check all system-relevant electrical and mechanical components, including the power supply, to eliminate the issue.

If a fault is not identified in this process, a software update may be necessary to eliminate the fault.

Software can be updated using Hella Gutmann macsRemote Services or a pass-thru-compatible Mega-Macs series diagnostic device. Furthermore, registered access to the vehicle manufacturer's

online portal is required. If the appropriate equipment is not available, please contact an authorised specialist workshop.

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval; indication of the document source is also required. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.