

# Audi TT - Reparation af sideblinklygte | HELLA

**Audi TT Årgang: 2002**  
**Reparation af sideblinklygte**  
Hvis der på ovennævnte model konstateres en defekt ved den ekstra sideblinklygte (fig. 1) eller ved fatningen, skal den repareres på følgende måde.- Afbryd spændingen.- Tryk blinklygten i kørselsretningen mod holdefligen, se pilens retning (fig. 2), og tag den ud af udsparingen i skærmen.- Træk huset af fatningen (fig. 3).- Udskift om nødvendigt pæren (fig. 3).- Foretag en funktionstest (fig. 4).- Monteringen foregår i omvendt rækkefølge.  
**Fig. 1 Fig. 2 Fig. 3 Fig. 4**  
**Blinklygte 9EL 270 107-011 Glødepære WY5W= 8GP 003 594-541 Hella art.-nr.:**

## Audi TT

Model year: 2002

### Returning side direction indicator to good working order

If the above-mentioned vehicle is found to have a defect in the additional side direction indicator (Fig.1) or in the bulb holder, this must be repaired as follows.

- Switch off the electrical system.
- Press the direction indicator forward against the retaining clip, see arrow direction (Fig.2); and remove it from its opening in the wing.
- Remove the housing from the bulb holder (Fig.3).
- Replace light source if necessary (Fig.3).
- Carry out performance check (Fig.4).
- Then remount the parts in reverse order.



Fig.1







Fig.2

Fig.3

Fig.4



WY5W



Direction indicator

9EL 270 107-011

Bulb

WY5W = 8GP 003 594-541

Hella article no.:

### **Important safety note**

Technical information and practical tips have been compiled by HELLA in order to provide professional support to vehicle workshops in their day-to-day work. The information provided on this website is intended for use by suitably qualified personnel only.

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval and indication of the source. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.