

# Jaguar F-Type - Nedsat ydelse af klimaanlæg | HELLA

**Jaguar F-Type Årgang: 10.2013-Stelnr.: K00103-Nedsat ydelse af klimaanlæg**  
Hvis der for ovennævnte modeller klages over utilstrækkelig køleeffekt, kan årsagen være en defekt trykreguleringsventil i kompressoren. Ofte viser en defekt trykreguleringsventil sig ved, at værdierne for høj- og lavtryk er atypiske: Højtryk lavt / lavtryk højt. Inden den elektronisk styrede ventil udskiftes, bør aktiveringen, systemets andre komponenter og mængden af kølemiddel dog først kontrolleres. Trykreguleringsventilen udskiftes på følgende måde:  
Sug kølemidlet ud  
Afmontér kompressoren (er oftest nødvendigt)  
Rens området omkring reguleringsventilen  
Afmontér ventilens låsering  
Tag forsigtigt reguleringsventilen af  
Kontroller området omkring ventilens placering i kompressoren for skader og tilsmudsning  
Smør den nye ventils tætningsringe med kompressorolie, og sæt den nye reguleringsventil på plads  
Monter låseringen  
Monter kompressoren  
Foretag en tæthedskontrol  
Fyld klimaanlægget, og foretag en funktionstest  
Illustrationen viser et eksempel på en kompressor med elektronisk styret trykreguleringsventil

## F-Type

**Model year: 10.2013-**

**Chassis no.: K00103-**

## Poor air-conditioning system performance

If the customer complains that the cooling power of the air-conditioning system in one of the aforementioned vehicles is insufficient, this may be due to a faulty pressure control valve in the compressor.

A faulty pressure control valve can often be identified by unusual high and low pressure: high pressure too low; low pressure too high.

However, before the electronically actuated valve is replaced, the controller, other system components and the coolant level should be checked.

To replace the compressor pressure control valve, proceed as follows:

- Drain off refrigerant
- Remove compressor (usually required)
- Clean area around control valve
- Remove circlip from valve
- Carefully remove control valve
- Check the area of the compressor into which the new valve is going to be inserted for damage and soiling
- Moisten the seal rings on the new valve with compressor oil, and insert the new control valve
- Fit circlip
- Fit compressor
- Carry out leak test
- Fill air-conditioning system and perform a functional test



The figure shows an example of compressor with an electronically actuated pressure control valve