

# Mazda RX-8 - Kontrollampen for kølevæskestand lyser | HELLA

**MazdaRX-8Alle modeller efter 10/2008Kontrollampen for kølevæskestand lyserHvis kontrollampen for kølevæskestand lyser i ovennævnte modeller, selv om kølevæskestanden er korrekt, kan årsagen være en defekt sensor for kølevæskestanden.I så fald skal sensoren for kølevæskestanden, ledningerne og stikket kontrolleres for skader hhv. elektrisk gennemgang.Hvis sensoren er svejset sammen med ekspansionsbeholderen, skal hele ekspansionsbeholderen udskiftes.Bilproducenten kan levere en ændret ekspansionsbeholder.Res.nr.: N3H1-15-350L**

## **RX-8**

**All models from 10/2008 onwards**

### **Lighting up of the coolant level warning light**

If the coolant level warning light comes on in the above-mentioned vehicles although the coolant level is correct, a possible cause of the trouble is a faulty coolant level sensor.

In such cases, the coolant level sensor, the lead and the plug are to be checked for any form of damage and also for continuity of electrical current.

If the sensor is welded to the expansion tank, then this tank has to be completely renewed.

The manufacturer now offers a modified coolant expansion tank for this purpose.

Spare part no.: N3H1-15-350L