

Mercedes Vaneo - Centrallås låser spontant op | HELLA

MercedesVaneoÅrgang: 2002 til 2005Centrallås med trådløs aktivering låser spontant op af sig selv.Hvis der for ovennævnte modeller klages over ovennævnte fejl, og hvis kabinebelysningen desuden ikke slukker automatisk under kørslen som normalt, kan det skyldes et kontaktproblem ved skydedørene.I fejlhukommelsen for systemet `Komfort , centrallås` kan fejlkoden B1101 være gemt.- B1101 betyder:Styreledning til låsepal 2 skal sikres.Denne fejlpostering kan forvirre, da denne styreledning ikke findes i modeller med trådløs fjernbetjening.I så fald kan det skyldes et elektrisk problem som følge af et for stramt ført ledningsbundt i skydedørene, hvorved der sker afbrydelse af stikforbindelsen ved den nederste dørkontakt. Som følge af denne afbrydelse modtager styreenheden ikke information om `Funktionstilstand, åben` og aktiverer den hermed tilknyttede kabinebelysning. Hvis der er brud på ledningen til dørkontakten, skal kontakten udskiftes, og ledningsbundtet føres, så det ikke ligger for stramt. Det skal ligeledes kontrolleres, at kontakterne kan bevæge sig frit.

Vaneo

Model year: 2002 to 2005

Radio-controlled central locking system unlocks itself.

If the above fault is complained of in these vehicles, and if the passenger compartment lighting also fails to switch off while driving, there may be a contact problem in one of the sliding doors.

Error code B1101 may be recorded in the error memory for the 'Comfort, central locking' system.

- B1101 is synonymous with "Check control line for nut2 of lock".

This error entry may be misleading, because this control line is not installed on vehicles with radio-controlled locking.

In this case there may be an electrical problem due to excessive tension in the cables in the sliding door causing a wire to come off the contact switch at the bottom. This prevents the control unit from receiving any information for 'function status, open' and it therefore activates the associated interior light. If the connection to the door contact switch is broken you will need to

replace the switch and reposition the cable set without tension. You should also make sure that the contacts can move freely.

The reprinting, distribution, reproduction, exploitation in any form and disclosure of the contents of this document, even in part, is prohibited without our express written approval and indication of the source. The schematic illustrations, figures and descriptions are for explanation and presentation of the document text and cannot be used as a basis for installation or design. All rights reserved.