



BMW 2 Series F46 - power steering stiff at full steering angle

Data sheet	
Manufacturer	BMW
Vehicle model	2 Series F46 Gran Tourer
Engine	2.0d
Year of manufacture	2015 - 2018
Symptoms	Power steering stiff at full steering angle
Recommended HGS tool	mega macs X

Important safety note

Technical information and practical tips have been compiled by HELLA in order to provide professional support to vehicle workshops in their work. The information provided on this website is intended for use by suitably qualified personnel only.

Power steering becomes sporadically stiff when manoeuvring or parking

With the above-mentioned vehicle type, the power steering may suddenly become stiff when manoeuvring or parking. The reason for this fault may be that the overheating protection has been incorrectly activated. As a result, the electric power steering switches to a safety mode that severely restricts its functionality.

If the above fault is present, this may be related to an error in the map of the installed software version of the electric power steering. This problem can be remedied by carrying out a software update. Check the software version of the electric power steering and update if necessary.

A software update can be carried out via Hella-Gutmann macsRemote Services, for example, or by using a pass-through capable diagnostic device from the mega macs series. Furthermore, registered access to the vehicle manufacturer's online portal is required. If the appropriate equipment is not available, please contact an authorised specialist workshop.

This defect may also occur in other models with the same type of power steering.

IMPORTANT

Please always follow the repair instructions from the vehicle manufacturer when carrying out such work!

Reprinting, distribution, reproduction, exploitation in any form whatsoever or disclosure of the contents of this document, even in part, is prohibited unless our express permission has been obtained in writing beforehand and the source is stated. The schematic illustrations, pictures and descriptions are provided for explanatory purposes and are only intended as a visual supplement to the document text, so they cannot be used as the basis for installation or assembly work. All rights reserved.