

Fiat Idea - Los intermitentes de emergencia se enciende sin haber presionado el interruptor | HELLA


Fiat

Idea

Todos los modelos con regulación manual de la calefacción y de la temperatura

Los intermitentes de emergencia se enciende sin haber presionado el interruptor.

Si en estos vehículos se detecta que los intermitentes de emergencia se encienden solos, puede deberse a un fallo interno del interruptor de dichos intermitentes.



En este último caso debe procederse de la siguiente manera:




Imagen 1.

Important safety note

The following technical information and tips for practical use have been set up by HELLA in order to offer professional support to automotive workshops in their daily work. The information available here on this website is only to be used by appropriately trained specialist staff.

The reprinting, distribution, reproduction, exploitation in any form and disclosure of the contents of this document, even in part, is prohibited without our express written approval and indication of the source. The schematic illustrations, figures and descriptions are for explanation and presentation of the document text and cannot be used as a basis for installation or design. All rights reserved.