

Mercedes – Benz - Projecteurs au xénon | HELLA

Mercedes – Benz

Lampe au xénon avec amorceur intégré

Lire le compteur d'heures de fonctionnement / Remettre à zéro

Pour certaines variantes, les informations relatives au nombre de minutes de fonctionnement des lampes au xénon sont mémorisées dans le module d'alimentation du projecteur au xénon.

Résolution:

Avant de procéder au remplacement de la lampe au xénon, lire le nombre de minutes de fonctionnement. La lecture de ces informations peut se faire via un appareil de diagnostic approprié.

Une fois le remplacement effectué, remettre à zéro le compteur d'heures de fonctionnement. (Fig. 1).

Recommandation :

- Toujours remplacer les sources luminesques par paire

 Home	 Diagnostics
Function:	Connection help
Basic setting	 Voltage: --- V
Assembly:	 Make sure: ► Connect suitable char
Resetting the counter for head	c plu c cor icati sec. - n.
Actuating the installation/removal position of the parking brake	
Initializing the adaptive cruise control	
Resetting the counter for headlight operating hours	
Resetting the counter for headlight cooling fan operating hours	
Learning the power windows	
Adjusting the headlights	

Exemple :(fig.1)

mega macs Hella-Gutmann

Fig. 1