

Opel Astra J - Accensione della spia dell'alternatore | HELLA

Opel

Astra J

Model Year: 2010 - 2012

Accensione della spia dell'alternatore

Codice di guasto B1517

Su questi veicoli è possibile che la spia dell'alternatore si accenda, nonostante la tensione della batteria e dell'alternatore siano corrette. Contemporaneamente nella centralina viene memorizzato il codice di guasto B1517 (03). Questo ha lo stesso significato di "Tensione batteria sotto il valore nominale".

Important safety note

Technical information and practical tips have been compiled by HELLA in order to provide professional support to vehicle workshops in their day-to-day work. The information provided on this website is intended for use by suitably qualified personnel only.

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval and indication of the source. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.