



## Porsche 911 (991): radiator fan error message

### Data sheet

|               |                                                                                       |
|---------------|---------------------------------------------------------------------------------------|
| Manufacturer  | Porsche                                                                               |
| Vehicle model | 911 (991)                                                                             |
| Engine        | All models                                                                            |
| Model year    | 2011 - 05.2016                                                                        |
| Symptoms      | Error message: "Radiator fan error, avoid full engine load, you may continue driving" |

### Important safety note

## Porsche 911 (991): radiator fan error message

If the following message appears in the above-mentioned vehicles while driving:

"Radiator fan error, avoid full engine load, you may continue driving",

this may be caused by a fault in the radiator fan.

The radiators are located on the left and right behind the air guide grille in the bumper ([Figure 1](#)). The fans themselves can be accessed from the wheel well if the wheel well trim ([Picture 2](#)) is removed first.

Check the wiring on both fans as well as the fans themselves for penetrated moisture to resolve the situation. If there is corrosion on the connectors, for example, this is a clear indication of the

cause of the error message. It is then necessary to clean the connections and, if necessary, repair them. The radiator fan may also need to be replaced.

**i IMPORTANT**

Figures show the right-hand side of the vehicle.



Figure 1: The radiators are located on the left and right behind the air guide grille in the bumper.



Figure 2: The fans can be accessed from the wheel well if the wheel well trim is removed first.

## **THIS MAY ALSO BE OF INTEREST TO YOU**

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval and indication of the source. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.