



## BMW 1 Series/3 Series/4 Series - Smell of fuel in the vehicle interior / passenger compartment

|                      |                                                                               |
|----------------------|-------------------------------------------------------------------------------|
| Data sheet           |                                                                               |
| Manufacturer         | BMW                                                                           |
| Vehicle model        | 1 Series / 3 Series / 4 Series                                                |
| Model series         | F20 / F30 / F31 / F32 / F33/ F34 / F35 / F36                                  |
| Engine               | N47                                                                           |
| Year of construction | 2013                                                                          |
| Symptoms             | Unpleasant odour (fuel smell) in the vehicle interior / passenger compartment |

### Important safety note

## BMW 1 Series/3 Series/4 Series - Unpleasant odour in the vehicle interior / passenger compartment (fuel smell)

In this repair case, the customer complains of an unpleasant odour (fuel smell) in the vehicle interior / passenger compartment.

The cause of the above-mentioned problem is a leaky fuel line.

Remedy: Replace the fuel line in accordance with the vehicle manufacturer's instructions.

After completion of the repair work, it is essential to check the fuel supply system and all connections for leaks before starting the engine and driving off.

| Spare parts required  | OE part number  |
|-----------------------|-----------------|
| Fuel supply line (1x) | 13 53 8 594 893 |
| Hose clamp (1x)       | 11 15 1 727 509 |
| Torx screw (4x)       | 07 14 7 270 121 |

### **IMPORTANT**

Please note that such work should only be carried out by an authorised specialist workshop and that the vehicle manufacturer's repair and maintenance instructions must be observed!

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval; indication of the document source is also required. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.