



Mercedes

Type: 124

Model year: up to November 1992

With engine: 104.942 | 104.992 | 111.960

ABS/ASR warning lights stay on or switch on and off sporadically

A loose contact in the overvoltage protection relay can lead to the ABS, ABS/ASR warning light not switching off after the engine has been switched on, or switching on sporadically when driving. In this case, check the fuse of the voltage supply for the overvoltage relay. Move the fuse to and fro to try to eliminate or reproduce the fault with the engine running. If this is possible, the relay must be replaced.

Bulletin

