



## Toyota Avensis (T22)

### Starter/ignition without function

With the above-mentioned vehicles it can occasionally happen that the ignition does not switch on or the starter is not triggered when the key is turned. It is often possible to start the vehicle after turning the ignition key backwards and forwards a few times. Usually, this problem is caused by a faulty contact part (Fig. 1) on the ignition lock. To replace the contact part proceed as follows:

- Remove the trim in the footwell on the driver's side
- Remove the lower steering wheel skirt. To do this, loosen the three attachment screws. To reach two of the screws, the steering wheel has to be turned through 90° out of centre to the right and left respectively
- Remove the plug-type contacts of the wiring from the contact part
- Remove the contact part by taking the two attachment screws out (Fig. 2)
- Install a new contact part and replace the trims in reverse order
- Carry out a functional test

