Bulletin



© Hella KGaA Hueck & Co., Lippstadt 21 February 2007 1-1

Peugeot 206 All models

Airbag control lamp flashes or illuminates permanently.

If there are complaints with the above vehicles that the airbag control lamp flashes or illuminates permanently after using the cut-out switch for the passenger airbag, two possible causes should be considered:

- Airbag control lamp illuminates permanently
 Passenger airbag was deactivated using the cut-out switch
- 2. Airbag control lamp flashes Failure of the cut-out switch.

If the airbag control lamp is flashing, no fault is stored in the fault memory. In order to eliminate the fault, the cut-out switch for the passenger airbag must be replaced.

Note:

From production number (last figures of the vehicle identification number) 8215XX, a modified cut-out switch for the passenger airbag was fitted during series production.



