## **Bulletin**



© Hella KGaA Hueck & Co., Lippstadt 18. Januar 2005 1-1

## BMW Mini (R50)

## **Bulb replacement / rear lamps**

In order to replace the bulbs in the rear lamps of the abovementioned vehicles, proceed as follows:

- Remove the luggage compartment cover
- Remove the side trim panel (Fig. 1, Item A)
- Remove the first-aid box (left-hand side only)
- Pull the connector off the bulb carrier
- Remove the attachment nut (Fig. 2)
- Press the clips (Fig. 3), remove the rear lamp

Installation takes place in reverse order.

If water has penetrated the lamp housing (Fig. 4), the rear lamp should be replaced.



Fig. 1




Fig. 2




Fig. 3



Fig. 4



