

Honda Civic VII — Desinfecção do evaporador | HELLA

Honda Civic VII Ano de fabrico: 2001–2005
Substituição do filtro do habitáculo
Desinfecção do evaporador
Para ter acesso ao filtro do habitáculo e realizar uma desinfecção do evaporador nos veículos supracitados, deve proceder-se da seguinte forma:
Desmontar o porta-luvas (Figura 1)
Retirar a cobertura da caixa do ventilador (Figura 2)
Retirar o filtro do habitáculo (Figura 3)
Introduzir a lança de pulverização para a desinfecção da superfície do evaporador (Figura 4)
Figura 3 Figura 4 Figura 1 Figura 2

Civic VII

Model year: 2001–2005

Replacement of the cabin filter

Disinfection of the evaporator

Proceed as follows to access the cabin filter on the vehicles listed above and perform a disinfection of the evaporator:

- Dismantle the glove compartment (figure 1)
- Remove the cover of the fan housing (figure 2)
- Pull out the cabin filter (figure 3)
- Insert the spray lance to disinfect the evaporator surface (figure 4)









Important safety note

The following technical information and tips for practical use have been set up by HELLA in order to offer professional support to automotive workshops in their daily work. The information available here on this website is only to be used by appropriately trained specialist staff.

The reprinting, distribution, reproduction, exploitation in any form and disclosure of the contents of this document, even in part, is prohibited without our express written approval and indication of the source. The schematic illustrations, figures and descriptions are for explanation and presentation of the document text and cannot be used as a basis for installation or design. All rights reserved.