

O Range Extender | HELLA

GeralO Range Extender (Figura 1), também designado por extensor de autonomia, é utilizado, entre outros, também em veículos elétricos (Opel Ampera, Chevrolet Volt ou BMW i3). Trata-se de um agregado adicional que aumenta a autonomia do veículo elétrico. Geralmente, os Range Extender são motores de combustão que acionam um alternador e alimentam o motor elétrico e os acumuladores com energia. **Figura 1** **Funcionamento** No sistema híbrido de série (Figura 2), a energia mecânica produzida pelo motor de combustão não é diretamente utilizada para a transmissão. Em vez disso, este aciona um alternador para a alimentação de energia do motor elétrico e dos acumuladores. Através do desacoplamento do Range Extender da cadeia cinemática mecânica, o agregado pode ser operado num binário/velocidade de rotação eficiente. Os desempenhos máximos (velocidade máxima e aceleração) são exclusivamente alcançados através da energia da bateria. Se o carregamento da bateria chegar a um ponto crítico, o Range Extender liga automaticamente, fornecendo assim a energia necessária para o motor elétrico. **Figura 2** **Causas da avaria** Como em todos os motores de combustão convencionais, as causas da avaria podem ser as seguintes. **Sem combustível** **Danos mecânicos** **Danos eletrônicos**

The range extender (Figure 1) is used, in many applications, including in electric vehicles (e.g. Opel Ampera, Chevrolet Volt, BMW i3).

It is an additional unit that extends the range of the electric vehicle.

Range extenders usually take the form of internal combustion engines, which drive an alternator in order to supply the electric motor and accumulators with current.



Figure 1

Function

In the serial hybrid system (Figure 2), the mechanical energy generated by the internal combustion engine is not used directly to drive the vehicle. Instead, it drives an alternator that supplies power to the electric motor and the accumulators.

By decoupling the range extender from the mechanical drive train, the unit can be operated in an efficient torque-speed range.

The maximum driving performance (top speed and acceleration) are achieved exclusively using the power supplied by the battery.

If the charge condition of the battery reaches a critical point, the range extender is activated automatically and thus supplies the energy required for the electric drive.




Figure 2

Causes of failure

As with any conventional internal combustion engine, the causes of failure may be as follows:

- Lack of fuel
- Mechanical damage
- Electronic damage

Important safety note

The following technical information and tips for practical use have been set up by HELLA in order to offer professional support to automotive workshops in their daily work. The information available here on this website is only to be used by appropriately trained specialist staff.

The reprinting, distribution, reproduction, exploitation in any form and disclosure of the contents of this document, even in part, is prohibited without our express written approval and indication of the source. The schematic illustrations, figures and descriptions are for explanation and presentation of the document text and cannot be used as a basis for installation or design. All rights reserved.